



Silvretta Easy Go model binding template, ©WildSnow.com 2008, publication by permission only.

Silvretta Easy Go binding template for front screw holes copyright WildSnow.com

Place heel and toe templates on ski using these measurements between these lines, check before drilling ski by laying binding parts on hole locations you mark on ski.
 Small: 308 mm
 Medium: 337 mm
 Large: 362 mm

Verify scale of printout -- this box should be 40 x 40 mm. If not, adjust settings. In Acrobat Reader to 100 % view, and check printer settings

to front of ski

Print several templates, cut to separate the toe and heel units, but leave plenty of tip/tail center line to work with.

Silvretta Easy Go binding template for rear screw holes copyright WildSnow.com

Recommendations and diagrams suggested herein are opinions only, and author takes no responsibility for, nor makes any warranty that the suggested templates conform to manufacturers suggested guidelines, or would conform to the requirements of some skiers, or to the varied terrain some skiers choose to ski. Use at your own risk. No warranty, expressed or implied.